

7857X 7656X VIPER UPGRADE



Brand: Clifford

Product Code: 7857X-7656X

Stock: 6

UPC: 93207101427

MPN: 7857X 7656X VIPER UPGRADE

Location: Cleveland, OH

Price: \$159.99

Short Description

Clifford 2-Way LED and 1-Way Remote Control Combo

Description

Brand New Viper 7858V 2-Way LED and 7657V 1-Way Remote Control Combo. Replacement for the Discontinued Clifford 7856X, 7857X and 7656X Remotes

Upgrade your compatible Clifford, Viper or Python remote start, security or security with remote start system with the newly redesigned Viper 7858V 2-way LED remote control and Viper 7657V 1-way companion remote combo. This remote control set replaces many discontinued Clifford 7856X, 7857X and 7656X remote controls while providing updated Viper styling, reliable operation and convenient replacement options for compatible systems.

The Viper 7858V rechargeable 2-way LED remote control features bright LED command confirmation, USB-C charging capability and up to 1-mile operating range. The included Viper 7657V 1-way companion remote gives you a second remote for another driver, spare use or everyday convenience.

This updated remote design features a slimmer profile for improved comfort, an upgraded USB-C charging port for better reliability and a clean button layout for quick access. The

LED command confirmation indicators are positioned for easy visibility, helping confirm remote commands when using the 7858V 2-way transmitter.

Purchase with confidence from Access 1 Alarm & Audio, Cleveland, Ohio's premier mobile electronics shop. Every Viper 7858V and 7657V remote control combo sold by Access 1 is a genuine Viper transmitter set sourced directly from the original manufacturer. No knockoffs, no refurbished units and no reprogrammed returns—just authentic Viper quality backed by knowledgeable support and years of experience.

Replacement Information

This Viper remote combo is a recommended replacement option for compatible systems that previously used the discontinued Clifford 7856X, Clifford 7857X and Clifford 7656X remote controls. Please verify compatibility with your system before ordering.

What You Will Receive

- One Brand New Viper 7858V 2-Way LED Remote Control
- One Brand New Viper 7657V 1-Way Companion Remote Control
- USB-C Charging Cable
- Programming Instructions
- Owner's Manual Link
- QA Card confirming the remote controls were tested prior to shipping

Compatible Clifford Matrix Systems

- DS3*
- DS3+*
- DS4*
- DS4+*
- 3606X
- 3806X
- 4606X
- 4806X
- 5606X
- 5806X
- 9856X
- D9857X

Compatible Viper Systems

- DS3*

- DS3+*
- DS4*
- DS4+*
- DS4V*
- DS4VP*
- 3606V
- 3806V
- 4606V
- 4806V
- 5606V
- 5806V
- 5808V
- 9857V
- D9857V

Compatible Python Systems

- DS3*
- DS3+*
- 4606P
- 4806P
- 5606P
- 5806P
- 9856P
- D9856P

Antenna Requirement

Systems marked with an asterisk (*) require a compatible 6866T, 6867T or A6868T antenna.

Programming Information

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control combo. Programming instructions are included with the package and require access to the valet/programming button on the windshield-mounted antenna. Please ensure your system has a compatible 2-way antenna installed.

Video programming assistance is available through our YouTube channel. If you have any questions regarding compatibility or programming, please contact us before ordering.

Please contact us if you have any questions regarding compatibility or programming.

Programming Instructions

Viper 7858V LED 2-Way 5-Button Remote Programming Instructions

The following routine is used to pair this remote control to a compatible system.

Remote Pairing Mode

1. Open a door.
2. Turn the ignition ON.
3. Within five seconds, press and release the Control Center button one time.
4. Within five seconds, press and hold the Control Center button. The status LED begins flashing in single-flash sequence and the siren/horn sounds, if connected, once to confirm the system is ready for remote pairing. Release the button.
5. Press and hold the **UNLOCK** button for eight seconds. The transmit LED will illuminate and the remote will emit one long beep indicating you have entered Pairing Mode. Promptly release the **UNLOCK** button.
6. Within two seconds, press and release the **UNLOCK** button. The remote will exit Pairing Mode if this step is not completed within two seconds.
7. Wait several seconds for pairing to complete. If connected, the horn or siren sounds indicating the pairing procedure was successful.

To Exit Pairing Mode On The Remote Control

Wait 30 seconds without pressing a command button on the remote control, or press and release the **F** button once, then press and hold until the transmit LED shuts off.

Programming Routine Exits If Any Of The Following Occurs

- The open door is closed.
- The ignition is turned OFF.
- There is no activity for an extended period.
- The control button is pressed too many times.

Specification

Remote Control

Works With Antenna(s)	6816T 6826T 6866T 6867T
Battery Type	Rechargeable Lithium-Ion
FCC ID	EZSDEI7856 and EZSDEI7656
IC Number	1513A-7856 and 1513A-7656
Frequency	915Mhz
Range	1-Mile+
1-Way or 2-Way	BOTH