Directed DSM550 SmartStart Module



Brand: Directed

Product Code: Directed DSM550

Phone: (216) 252-3000 - Email:

sales@access1alarm.com

Availability: In Stock UPC: 93207104008 MPN: Directed DSM550

Price: \$199.99

Short Description

Add a Directed SmartStart GPS module to any compatible Avital, Astrostart, Automate, Clifford, Python or Viper system to make your system SmartStart ready.

Description

GPS tracking and vehicle control in stand-alone mode or when connected to a compatible Directed system. This GPS module will also enable the SmartStart GPS location-based features.

Key Features:

- Smart phone interface
- 4G LTE
- GPS tracking
- Virtually unlimited range!
- Lock, unlock, trunk release when connected to a compatible Viper system
- Low battery voltage warning
- Location Monitoring, Speed Monitoring, Tow/Movement Alerts with GPS plan
- BONUS! FREE Roadside Assistance included
- BONUS! FREE 1-year basic subscription plan included (no 2-way capability)
- Disable your vehicle remotely Extra charge, please contact us regarding

price and options

Includes:

- All Required Harnesses for Installation
- Professional Installation at time of install of Viper system or added charge for later installation or in stand-alone mode
- Lifetime Labor Warranty

Videos

OUR WARRANTY

Access 1 Alarm & Audio provides to the ORIGINAL owner a lifetime warranty on the installed system and includes the Control Module (brain), Antenna, Program Switch. LED and labor.

NOTE: The lifetime warranty DOES NOT include remote controls, which are covered by a 1-year warranty against defects.

NOTE: Disconnecting or modifying the wiring by anyone other than Access 1 Alarm & Audio VOIDS the warranty.

NOTE: If technology moves on and your system is obsolete due to the country's infrastructure progressing, we can't warranty the system. As what happened with the 2G cellular network.

Specification

Remote Start System Brand Directed 1-Way or 2-Way Audible & Visual Confirmation Horn Feedback Depends on Installed Viper System Comfort & Convenience Controls Heated Seats Activation Depends on Installed Viper System Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Poor Lock Control Yes Door Lock Control Yes Door Unlock Control Yes Door Unlock Control Yes Door Unlock Control Yes Doriver Priority Unlock No Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass-Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Function or Feature Status Brake Status Depends on Installed Viper System Pends on Installed Viper System Depends on Installed Viper System				
Audible & Visual Confirmation Horn Feedback Parking Lights Control Comfort & Convenience Controls Heated Seats Activation Depends on Installed Viper System Activation OEM Door Lock & Alarm Controls Arm Factory Security Pes Door Lock Control Pes Door Unlock Control Pes Door Unlock Control Pes Door Unlock Control Pes Doriver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System	Brand	Directed		
Audible & Visual Confirmation Horn Feedback Parking Lights Control Comfort & Convenience Controls Heated Seats Activation Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Pisarm Factory Security Poor Lock Control Portional Priority Unlock Priver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System Installed Viper System Depends on Installed Viper System	1-Way or 2-Way			
Horn Feedback Parking Lights Control Comfort & Convenience Controls Heated Seats Activation Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Poor Lock Control Point Priority Unlock Priority Unlock Priority OEM Control Control of aftermarket alarm with OEM remote Integrated Security & Monitoring Entry Monitoring Hood Pin Entry Monitoring Hood Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System				
Parking Lights Control Comfort & Convenience Controls Heated Seats Activation Rear Window Defogger Activation OEM Door Lock & Alarm Controls Depends on Installed Viper System Depends on Installed Viper System OEM Door Lock & Alarm Controls Arm Factory Security Yes Disarm Factory Security Yes Door Lock Control Yes Door Unlock Control Yes Door Unlock Control Yes Doriver Priority Unlock No Trunk / Hatch Release Pactory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass-Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System				
Comfort & Convenience Controls Heated Seats Activation Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Pes Disarm Factory Security Pes Door Lock Control Trunk / Hatch Release Pattory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Function or Feature Status Brake Status Depends on Installed Viper System				
Heated Seats Activation Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Disarm Factory Security Poor Lock Control Poriver Priority Unlock Trunk / Hatch Release Pactory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System		·		
Rear Window Defogger Activation OEM Door Lock & Alarm Controls Arm Factory Security Disarm Factory Security Poor Lock Control Door Unlock Control Priver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System				
Activation OEM Door Lock & Alarm Controls Arm Factory Security Disarm Factory Security Pes Door Lock Control Pes Door Unlock Control Pes Driver Priority Unlock No Trunk / Hatch Release Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System				
OEM Door Lock & Alarm Controls Arm Factory Security Yes Disarm Factory Security Yes Door Lock Control Yes Door Unlock Control Yes Driver Priority Unlock No Trunk / Hatch Release Optional Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass-Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System		2 openiae en metamea riper eyetem		
Arm Factory Security Disarm Factory Security Pes Door Lock Control Pes Door Unlock Control Pes Doriver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Pin Function or Feature Status Brake Status Depends on Installed Viper System Depends on Installed Viper System Ignition Status Depends on Installed Viper System Dem FOB OEM FOB OEM Remote Start Depends on Installed Viper System		Controls		
Disarm Factory Security Door Lock Control Pes Door Unlock Control Pes Driver Priority Unlock Prunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System Dem FOB 3x Lock Stop Using Depends on Installed Viper System Dem FOB OEM Remote Start Depends on Installed Viper System				
Door Lock Control Yes Door Unlock Control Yes Driver Priority Unlock No Trunk / Hatch Release Optional Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass-Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Installed Viper System Depends on Installed Viper System Depends on Installed Viper System	•			
Door Unlock Control Driver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System	-			
Driver Priority Unlock Trunk / Hatch Release Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System				
Trunk / Hatch Release Optional Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring				
Factory FOB Control Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Brake Status Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System Depends on Installed Viper System E-Brake Status Depends on Installed Viper System		-		
Control of aftermarket alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System				
alarm with OEM remote Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB OEM Remote Start Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System		Depends on Installed Viper System		
Transponder & Immobilizer Override Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System		_ op on as on moralises in post of orders.		
Immobilizer Bypass- Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB OEM FOB OEM Remote Start Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System		zer Override		
Data No Key Required Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB OEM FOB OEM Remote Start Depends on Installed Viper System				
Integrated Security & Monitoring Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status E-Brake Status Depends on Installed Viper System Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Remote Start & Engine Controls 3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System	ļ , , , , , , , , , , , , , , , , , , ,			
Entry Monitoring ALL Door Pins Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System OEM FOB 3x Lock Stop Using Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System				
Entry Monitoring Hood Pin Entry Monitoring Entry Monitoring Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System OEM FOB 3x Lock Stop Using Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System				
Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB OEM FOB OEM Remote Start Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System	_			
Pin Entry Monitoring Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB OEM FOB OEM Remote Start Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System	Entry Monitoring Hood	Depends on Installed Viper System		
Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System				
Trunk/Hatch Pin Function or Feature Status Brake Status Depends on Installed Viper System E-Brake Status Depends on Installed Viper System Ignition Status Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System	Entry Monitoring	Depends on Installed Viper System		
Brake Status E-Brake Status Depends on Installed Viper System		·		
E-Brake Status Ignition Status Depends on Installed Viper System Depends on Installed Viper System Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System OEM FOB Depends on Installed Viper System	Trunk/Hatch Pin			
Ignition Status Remote Start & Engine Controls 3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System		JS		
Remote Start & Engine Controls 3x Lock Start Using Depends on Installed Viper System OEM FOB OEM FOB OEM Remote Start Depends on Installed Viper System Depends on Installed Viper System	Function or Feature Statu			
3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System	Function or Feature Statu Brake Status	Depends on Installed Viper System		
OEM FOB 3x Lock Stop Using Depends on Installed Viper System OEM FOB OEM Remote Start Depends on Installed Viper System	Function or Feature Statu Brake Status E-Brake Status	Depends on Installed Viper System Depends on Installed Viper System		
3x Lock Stop Using OEM FOB OEM Remote Start Depends on Installed Viper System Depends on Installed Viper System	Function or Feature Statu Brake Status E-Brake Status Ignition Status	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System		
OEM FOB OEM Remote Start Depends on Installed Viper System	Function or Feature Statu Brake Status E-Brake Status Ignition Status Remote Start & Engine C	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls		
OEM FOB OEM Remote Start Depends on Installed Viper System	Function or Feature Statu Brake Status E-Brake Status Ignition Status Remote Start & Engine C 3x Lock Start Using	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls		
1 7	Function or Feature Statu Brake Status E-Brake Status Ignition Status Remote Start & Engine C 3x Lock Start Using OEM FOB	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls Depends on Installed Viper System		
Activation With RF Kit	Function or Feature Statu Brake Status E-Brake Status Ignition Status Remote Start & Engine C 3x Lock Start Using OEM FOB 3x Lock Stop Using	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls Depends on Installed Viper System		
	Function or Feature Statu Brake Status E-Brake Status Ignition Status Remote Start & Engine C 3x Lock Start Using OEM FOB 3x Lock Stop Using OEM FOB	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls Depends on Installed Viper System Depends on Installed Viper System		
Remote Start Takeover Most Vehicles	Function or Feature Status Brake Status E-Brake Status Ignition Status Remote Start & Engine Common Start Start Using OEM FOB 3x Lock Stop Using OEM FOB OEM Remote Start	Depends on Installed Viper System Depends on Installed Viper System Depends on Installed Viper System Controls Depends on Installed Viper System Depends on Installed Viper System		

Included Aftermarket Remote Controls (Quanity)	Depends on Installed Viper System
Included Aftermarket Remote Controls Range	Depends on Installed Viper System
Bluetooth Smartphone Control	N/A
Security Alarm Add-On Availabilty	
Add-On Security Available	Depends on Installed Viper System
Tilt and shock senors with security add-on	Depends on Installed Viper System
Siren with security add- on	Depends on Installed Viper System