

7816V



Brand: Viper
Product Code: 7816V - 7817
Availability: 4
UPC: 093207096785
FCC ID: ezsdei7816
MPN: 7816V 7817V
Location: Cleveland, Ohio

Price: \$129.99

Short Description

Viper LED 2-Way Remote

Description

Brand NEW Viper 7817V 2-Way 1-Button 1-Mile Range Replacement Remote Control Transmitter For The Discontinued Viper 7816V Remote Control, Including The Clifford 7816X and Python 7816X

This NEW Viper 7817V replacement remote control is the standard 2-way remote control for many of the Viper systems such as the 4816V and D9816V systems. Looking for a replacement Viper remote control for your system or just need an additional remote control? Buy brand new from Access 1 Alarm and Audio!

Have one of the older systems with the 7816V remote controls? This is the new and improved version of that remote control. This is Viper's 2nd generation of this style remote control and is redesigned with improved reliability, range and ergonomics. Battery replacement is much easier also. This remote control will also replace the AstroStart 2621D-TX, Automate 7816V, Avital 7817L, Clifford 7816X and the Python 7816P,

Whether you're replacing a lost remote or adding an extra for convenience, this

7817V is the perfect solution. Shop with confidence at Access 1 Alarm and Audio — where you'll receive brand-new, **GENUINE** remote controls direct from the original manufacturer. No knock-offs. No reprogrammed returns. Just authentic Viper quality.

What you will receive NEW:

- 7817V 2-Way Remote Control
- Programming Instructions

Works with the following Viper systems

- 4811V
- 4816V
- 9816V
- D9816V
- DS4816V

Works with the following AstroStart systems

- AFRFD2621

Works with the following Automate systems

- 4816A
- D9816A

Works with the following Clifford systems

- 4811X
- 4816X
- 9816X
- D9816X

Works with the following Python systems

- 4811P
- 4816P

- 9816P
- D9816P

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included with the package and will require accessing your windshield mounted antenna's valet/programming switch. Video instructions will be available on our YouTube page under remote controls. Please contact us if you have any questions.

Why buy from us? Well, we are the experts that only believe in perfection, from the quality of our images to the accurate description in each and every listing.

Programming Your Remote Control

Note: Make sure the system is disarmed, and the Control Center (windshield mounted antenna) LED is completely OFF for a minimum of 60-seconds prior to beginning the remote pairing process.

Preparing the system

1. Open drivers door
2. Turn the ignition ON.
3. Within 10-seconds, press and release once, then press and hold the system's Control Center (The Windshield Mounted Antenna) Valet button. The status LED begins flashing and the siren/horn (if connected) sounds to confirm the system is ready for pairing.
4. Release the Control Center's Valet button.

Pairing the remote control

1. Press and hold the remote start button (approximately 8-seconds)
2. Wait for the Transmit LED to light solid and the remote to beep. Release the remote start button
3. Within 2 seconds, press and release the remote start button. Wait several seconds for the pairing to complete, the vehicle's horn will honk if connected. You have now successfully learned the remote control to the vehicle's remote start system.
4. Turn the ignition OFF and WAIT approximately 60 seconds.

Note: 2-Way remotes will emit tones and provide visual confirmation that the

remote has successfully paired with the system. 1-Way remotes do not offer pairing confirmation.

Please contact us if you have any questions.