7857X Replacement Viper 7858V



Brand: Clifford
Product Code: 7857X-7858V
Stock: 10
UPC: 93207101427
MPN: 7857X-7858V
Location: Cleveland, OH

Price: $136.99

Short Description
Replaces Clifford 2-Way 1-Mile Remote Control

Description

Brand New Viper 7858V Rechargeable 2-Way LED Remote Control. Replacement for the Discontinued Clifford 7857X

The Viper 7858V rechargeable 2-way LED remote control is the current replacement for the discontinued Clifford 7857X remote control. Featuring bright LED command confirmation, USB charging capability and up to 1-mile operating range, the Viper 7858V provides reliable two-way communication for compatible Viper, Clifford, Python and Directed Electronics remote start and security systems.

The Viper 7858V is designed for compatible DS3, DS3+, DS4, DS4+, DS4X, DS4XP and many 2-way LED remote start and security systems using compatible 2-way antenna kits. It is a great replacement option for customers who previously used the Clifford 7857X or need a new rechargeable LED 2-way remote control.

Purchase with confidence from Access 1 Alarm & Audio, Cleveland, Ohio's premier mobile electronics shop. Every Viper 7858V remote control sold by Access 1 is a genuine Viper transmitter sourced directly from the original manufacturer. No knockoffs, no refurbished units and no reprogrammed returns—just authentic Viper quality backed by knowledgeable support and years of experience.

Replacement Information

The Viper 7858V is the current replacement for the discontinued Clifford 7857X rechargeable 2-way LED remote control. Please verify compatibility with your system before ordering.

What You Will Receive

- One Brand New Viper 7858V 2-Way LED Remote Control
- Programming Instructions

Compatible Viper Systems

- 3606V
- 3706V
- 3806V
- 4606V
- 4706V
- 4806V
- 5606V
- 5706V
- 5806V
- DS3
- DS3+
- DS4
- DS4+
- DS4X
- DS4XP

Compatible Clifford Systems

- 3606X
- 3706X
- 3806X
- 4606X
- 4706X
- 4806X
- 5606X
- 5706X
- 5806X
- DS3
- DS3+

- DS4
- DS4+
- DS4X
- DS4XP

Compatible RF Kits

- 9656V
- 9756V
- 9856V
- 9656X
- 9756X
- 9856X

Programming Information

Please make sure you have a working control unit installed in the vehicle prior to ordering this remote control. Programming instructions are included with the package and require access to the valet/programming button on the windshield-mounted antenna. Please ensure your system has a compatible 2-way antenna installed.

Video programming assistance is available through our YouTube channel. If you have any questions regarding compatibility or programming, please contact us before ordering.

Viper 7858V LED 2-Way 5-Button Remote Programming Instructions

The following routine is used to pair this remote control to a compatible system.

Remote Pairing Mode

1. Open a door.
2. Turn the ignition ON.
3. Within five seconds, press and release the Control Center button one time.
4. Within five seconds, press and hold the Control Center button. The status LED begins flashing in single-flash sequence and the siren/horn sounds, if connected, once to confirm the system is ready for remote pairing. Release the button.
5. Press and hold the **UNLOCK** button for eight seconds. The transmit LED will illuminate and the remote will emit one long beep indicating you have entered Pairing Mode. Promptly release the **UNLOCK** button.
6. Within two seconds, press and release the **UNLOCK** button. The remote will exit Pairing Mode if this step is not completed within two seconds.

7. Wait several seconds for pairing to complete. If connected, the horn or siren sounds indicating the pairing procedure was successful.

To Exit Pairing Mode On The Remote Control

Wait 30 seconds without pressing a command button on the remote control, or press and release the **F** button once, then press and hold until the transmit LED shuts off.

Programming Routine Exits If Any Of The Following Occurs

- The open door is closed.
- The ignition is turned OFF.
- There is no activity for an extended period.
- The control button is pressed too many times.

Visit Our YouTube Channel

Please contact us if you have any questions regarding compatibility or programming.

Programming Videos

Viper 7858V LED 2-Way 5-Button Remote Programming Instructions

The following routine is used to pair this remote control to a compatible system.

Remote Pairing Mode

1. Open a door.
2. Turn the ignition ON.
3. Within five seconds, press and release the Control Center button one time.
4. Within five seconds, press and hold the Control Center button. The status LED begins flashing in single-flash sequence and the siren/horn sounds, if connected, once to confirm the system is ready for remote pairing. Release the button.
5. Press and hold the **UNLOCK** button for eight seconds. The transmit LED will illuminate and the remote will emit one long beep indicating you have entered Pairing Mode. Promptly release the **UNLOCK** button.
6. Within two seconds, press and release the **UNLOCK** button. The remote will exit Pairing Mode if this step is not completed within two seconds.
7. Wait several seconds for pairing to complete. If connected, the horn or siren sounds indicating the pairing procedure was successful.

To Exit Pairing Mode On The Remote Control

Wait 30 seconds without pressing a command button on the remote control, or press and release the **F** button once, then press and hold until the transmit LED shuts off.

Programming Routine Exits If Any Of The Following Occurs

- The open door is closed.
- The ignition is turned OFF.
- There is no activity for an extended period.
- The control button is pressed too many times.

Specification

Remote Control	
Works With Antenna(s)	6816T 6826T 6866T 6867T A6868T
Battery Type	Rechargeable Lithium-Ion
FCC ID	EZSDEI7856
IC Number	1513A-7856
Frequency	915Mhz
Range	1-Mile+
1-Way or 2-Way	2-Way