7345V Remote Control



Brand: Viper
Product Code: 7345V
Stock: 3
UPC: 093207095009
FCC ID: EZSDEI489
MPN: Viper 7345V
Location: Cleveland, OH

Price: $139.99

Short Description

Genuine **Viper 7345V Responder LCD 2-Way Remote Control** with up to 1/4-mile range for compatible Viper, Python, Clifford Matrix, Automate, Avital and Mesa security and remote-start systems. Brand new with AAA battery included. **$139.99 with FREE U.S. shipping.**

Description

Genuine Viper 7345V Responder LCD 2-Way Remote Control

Looking for a replacement **Viper 7345V remote control** or an additional remote for your compatible Viper or Directed security and remote-start system? Access 1 Alarm & Audio supplies a **brand-new genuine Viper 7345V** from the original manufacturer — not a used, refurbished or reprogrammed remote.

The Viper 7345V Responder LCD is a **2-way remote control with up to 1/4-mile**

range, providing visual and audible confirmation of compatible security and remote-start commands.

$139.99 FREE Shipping in the USA

GENUINE VIPER Brand-new original replacement remote control

2-WAY LCD Visual and audible command confirmation

434 MHz Designed for compatible Directed receiver systems

UP TO 1/4 MILE Long-range operation with compatible systems

Viper 7345V Replacement Remote Control

The **Viper 7345V** is a genuine 2-way LCD replacement remote used with a wide range of compatible Viper and Directed Electronics security and remote-start systems. It can replace a lost or damaged 7345V, be added as an additional remote to a compatible system, or replace several compatible legacy remote-control models.

Although the replacement remote carries the Viper name, compatible Directed systems were also sold under the **Python, Clifford Matrix, Automate, Avital and Mesa** brands. Compatibility is determined by the installed system and receiver/control center — not by the vehicle's year, make or model.

7345V Compatible & Replacement Remote Models

The Viper 7345V can be used with compatible systems that originally operated with the following remote controls:

VIPER 489V 7341V
PYTHON 489P 7341P
CLIFFORD 489X 489XD 7341X 7345X
AUTOMATE 7344A
AVITAL 7345L

Viper 7345V Specifications

Remote Type 2-Way LCD
Operating Range Up to 1/4 Mile
Frequency 434 MHz

Battery	1 × AAA Replaceable

Viper 7345V System Compatibility

The **Viper 7345V** works with select Viper, Python, Clifford Matrix, Automate, Avital and Mesa security and remote-start systems using a compatible receiver/control center.

VIPER

- 3305V
- 4305V
- 5305V
- Responder 350
- 5000
- 5002

PYTHON

- Responder 460
- 3305P
- 5305P
- 900
- 902

CLIFFORD MATRIX

- Matrix 1X
- Matrix 10.5
- Matrix 12.5X
- 3305X
- Matrix 5305X
- 5305

- Matrix 5325X

AUTOMATE

- 5305A

AVITAL

- 3305L
- 5305

MESA

- 3307VM
- 5307VM

IMPORTANT COMPATIBILITY INFORMATION:

Remote-control compatibility is determined by the **security/remote-start system and receiver/control center installed in the vehicle**, not by the vehicle's year, make or model.

If a **Viper 7345V previously operated your system**, another genuine Viper 7345V is the correct replacement.

If you are replacing a different remote-control model, verify the original remote number and installed system before ordering. Compatibility can depend on the system model, date code and Control Center / Antenna installed in the vehicle.

> **AAA Battery Included:** Your new Viper 7345V includes one replaceable AAA battery. The battery may be packaged with a protective plastic isolator. Remove the protective plastic before attempting to operate or program the remote.

Programming Your Viper 7345V Remote

The 7345V must be paired with the compatible security or remote-start system installed in your vehicle before use. Programming requires access to the system's valet/programming button or windshield-mounted Control Center / Antenna.

Programming procedures vary depending on the system and Control Center installed in the vehicle. Complete Viper 7345V programming instructions are provided separately in the **Programming Instructions** tab on this page.

{ "@context": "https://schema.org", "@type": "Product", "@id": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-remote-control#product", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-remote-control", "name": "Viper 7345V Responder LCD 2-Way Remote Control", "description": "Genuine Viper 7345V Responder LCD 2-way replacement remote control with up to 1/4-mile range for compatible Viper and Directed security and remote-start systems.", "image": "https://www.access1alarm.com/images/com_eshop/products/viper-7345v-remote.jpg", "sku": "7345V", "mpn": "7345V", "brand": { "@type": "Brand", "name": "Viper" }, "additionalProperty": [{ "@type": "PropertyValue", "name": "Remote Type", "value": "2-Way LCD" }, { "@type": "PropertyValue", "name": "Operating Range", "value": "Up to 1/4 Mile" }, { "@type": "PropertyValue", "name": "Frequency", "value": "434 MHz" }, { "@type": "PropertyValue", "name": "Battery", "value": "1 AAA Replaceable Battery" }], "offers": { "@type": "Offer", "url": "https://www.access1alarm.com/car-alarms-and-remote-start/remote-controls/viper/7345v/7345v-remote-control", "priceCurrency": "USD", "price": "139.99", "availability": "https://schema.org/InStock",

"itemCondition": "https://schema.org/NewCondition", "shippingDetails": { "@type": "OfferShippingDetails", "shippingRate": { "@type": "MonetaryAmount", "value": "0", "currency": "USD" }, "shippingDestination": { "@type": "DefinedRegion", "addressCountry": "US" } }, "seller": { "@type": "Organization", "name": "Access 1 Alarm & Audio", "url": "https://www.access1alarm.com/" } } }

Programming Instructions

Viper 7345V Remote Control Programming Instructions

The **Viper 7345V** must be paired to the security or remote-start system installed in the vehicle before it can be used.

The correct programming procedure depends on whether your installed system is a **Security + Remote Start system** or a **Security Only system**.

IMPORTANT — LOCATE YOUR PROGRAMMING BUTTON FIRST

Depending on the age and configuration of your system, the programming button may be located in one of two places:

- **Separate Valet / Program Switch:** Older installations may have a separate small push-button switch hidden underneath the driver's side dashboard.
- **Control Center / Antenna:** Other systems use the programming button incorporated into the windshield-mounted Control Center / Antenna.

Both buttons serve the same programming purpose in the routines below. Use whichever programming button is installed with your system.

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.
3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button one time**.
4. **Hold:** Within five seconds, press the same programming button one more time and **continue holding it**. The LED will flash one time and the siren will chirp to confirm entry into remote programming. **Do not release the button.**
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The siren will chirp to confirm that the remote has been programmed.
6. **Release:** Release the programming button and turn the ignition key to **OFF**.

1. **Door:** Open a vehicle door and leave it open.
2. **Key:** Turn the ignition key to the **ON** position. Do not start the vehicle.
3. **Choose:** Within five seconds, press and release the **Valet / Program button or Control Center / Antenna button seven times**.
4. **Hold:** Press the same programming button one more time and **continue holding it**. The LED will flash seven times and the siren will chirp to confirm the selected programming channel. **Do not release the button.**
5. **Transmit:** While continuing to hold the programming button, press the **LOCK button** on the Viper 7345V. The unit will chirp to confirm that the remote has

been paired to the receiver.

6. **Release:** Release the programming button and turn the ignition key to **OFF**.

> **NOTE:** If the system does not enter programming mode, first verify that you are using the correct programming button for your installation. Some vehicles have the **Valet / Program switch hidden underneath the dashboard**, while others use the button on the **windshield-mounted Control Center / Antenna**.

Programming Complete

After programming is complete, turn the ignition OFF and test the Viper 7345V by locking and unlocking the system. A properly paired 2-way remote should provide confirmation from the compatible system.

Viper Remote Control Programming Video

Need additional help? Watch our remote-control programming video for a visual walkthrough of the pairing process.

WATCH PROGRAMMING VIDEO